## GFW-KEYBENCH-WD (ALL MODELS)

WOODEN KEYBOARD AND PIANO BENCH



Assembly Instructions: READ THIS DOCUMENT CAREFULLY BEFORE ASSEMBLY AND USE. KEEP THIS IN A SAFE PLACE FOR REFERENCE.



## IMPORTANT SAFETY INFORMATION


- Periodically check that nuts are tight after repeated use.
- Always use the bench on a level surface with all (4) legs touching the ground.
  - This product is designed for a single person sitting centrally.
- DO NOT stand on, lean on, or use the bench other than for its intended use.
  - Never exceed bench weight limit of 350lbs (158kg).
  - To clean, use non-abrasive cloth with mild soap and water.















- 1) Remove bench and legs from box, place bench seat upside down on flat clean surface.
- 2) Insert leg bolt through bench bracket hole.
- 3) Place a washer and then a lock washer onto the leg bolt.
- 4) Tighten the nut with wrench until the leg bolt is secure. (DO NOT OVERTIGHTEN)
- 5) Repeat steps 2-4 until all four (4) legs are attached, then flip over assembled bench.



