

# GFW-ELITEDESKCRNR

ELITE WORKSTATION CORNER DESK

## ASSEMBLY INSTRUCTIONS

# GATOR FRAMEWORKS



THIS PRODUCT COMES AS TWO (2) PACKAGES.

**Top: (1 of 2)**


Dimensions: 31"/79cm x 31"/79cm x 1.5"/4cm

Weight: 19lbs/8.7kg


**Legs: (2 of 2)**

Dimensions: 29.5"/75cm x 8"/20cm x 8"/20cm

Weight: 7.7lbs/3.5kg



Corner Desk: **100lbs (evenly distributed)**



5112 W. Linebaugh Ave. • Tampa, FL • Phone: (+1) 813.221.4191 • Fax (+1) 813.221.4181

©2021 Gator Co. • Visit [www.gatorframeworks.com](http://www.gatorframeworks.com) for more service & product information • All rights reserved

# CAUTION



FAILURE TO FOLLOW THESE WARNINGS OR FOLLOWING ASSEMBLY INSTRUCTIONS, MAY RESULT IN PROPERTY DAMAGE, SERIOUS BODILY INJURY OR DEATH.

- This unit contains small parts and packaging which could be a choking hazard for small children. Children should always be under adult supervision.
- Always unload unit and unplug all cables prior to moving the unit. The weight of personal belongings, or a snagged cable could cause the unit to become unstable and either tip or collapse.
- Do not slide the unit across the floor, as this may cause leg failure and the workstation could collapse.
- Do not overload any surface of the unit. The top could collapse. (See cover page for max weight load)
- Corner table must be secured to the workstation top or the rack table with the provided brackets and hardware.
- Do not climb, step, or excessively lean on the unit. The unit may become unstable and either tip or collapse.
- Do not attach or overload the sides, rear, or front of the unit, unless specified as an accessory, as this can create a force which can cause the unit to tip.
- Use hand tools for assembly to prevent damage like stripping or overtightening hardware.
- You may use a power drill to pre-drill holes for attaching brackets. Be sure to follow proper safety procedures when using power tools.
- We recommend you protect your work surface during assembly to prevent scratching or damage to tabletops, wood floors, etc.
- Legs have a removable inner panel which allows for routing cables down the legs. All cables must be disconnected before moving equipment, or unit could become unstable and either tip or collapse.
- It is recommended to have assistance when assembly steps require flipping unit over, or units require moving into place.
- Exercise caution if you see this (symbol)  in the instruction guide.
- Wipe clean with a cloth dampened in a mild cleaner, then wipe dry with a clean cloth.




# CONFIGURATIONS


CORNER DESK CAN BE REVERSED AND USED IN MULTIPLE ORIENTATIONS



## CORNER WITH WORKSTATION



## CORNER WITH WORKSTATION & RACK TABLE




# HARDWARE


VERIFY YOU HAVE ALL NECESSARY HARDWARE. WE EVEN SENT YOU EXTRA.



**28x**





**2x**



**2x**





# PARTS

PARTS COME IN MULTIPLE BOXES. MAKE SURE YOU HAVE EVERYTHING BEFORE ASSEMBLY.




**2x**


**1**




2




3



4



5



CABLE PASS-THROUGH LEGS

