# **GFW-ELITEKEYTBL**

ELITE KEYBOARD TABLE WITH SECOND (2ND) TIER

**ASSEMBLY INSTRUCTIONS** 

# **GATOR FRAMEWORKS**



### **GFW-ELITEKEYTBL61**

THIS PRODUCT COMES AS TWO (2) PACKAGES. Top & 2nd Tier: (1 of 2)

Dimensions: 40.5"/103cm x 16"/41cm x 3"/7.5cm Weight: 25.3lbs/11.5kg

Legs & Cable Management: (2 of 2)

Dimensions: 30.3"/77cm x 7.5"/19cm x 6.75"/17cm

Weight: 13.2lbs/6kg

### **GFW-ELITEKEYTBL88**

THIS PRODUCT COMES AS TWO (2) PACKAGES.

Top & 2nd Tier: (1 of 2)


Dimensions: 62.2"/158cm x 16.5"/42cm x 5.1"/13cm

Weight: 53lbs/20kg

Legs & Cable Management: (2 of 2)

Dimensions: 30.3"/77cm x 7.5"/19cm x 6.75"/17cm


Weight: 13.2lbs/6kg





Keyboard Table: 250lbs (evenly distributed)

Top: 200lbs 2nd Tier: 50lbs








- This unit contains small parts and packaging which could be a choking hazard for small children.
   Children should always be under adult supervision.
- Always unload unit and unplug all cables prior to moving the unit. The weight of personal belongings,
   or a snagged cable could cause the unit to become unstable and either tip or collapse.
- · Do not slide the unit across the floor, as this may cause leg failure and the workstation could collapse.
- Do not overload any surface of the unit. The top or shelves could collapse. (See cover page for max weight load)
- Second (2nd) tier shelf must be secured to the top with the provided bracket and hardware.
- Do not climb, step, or excessively lean on the unit. The unit may become unstable and either tip or collapse.
- · Do not force lift top closed or put any part of the body between lift top as it is closing.
  - Do not attach or overload the sides, rear, or front of the unit, unless specified as an accessory, as this
- · can create a force which can cause the unit to tip.
- After mounting the cam posts and dowels to the panels, be careful to not hit the cam posts and dowels
  prior to final assembly as damage and misalignment can occur to the mounting of the parts. This may
  cause the unit to not assemble correctly and create an unstable unit.
- · Use hand tools for assembly to prevent damage like stripping or overtightening hardware.
- You may use a power drill to pre-drill holes for attaching cable management and brackets. Be sure to follow proper safety procedures when using power tools.
- We recommend you protect your work surface during assembly to prevent scratching or damage to tabletops, wood floors, etc.
- Legs have a removable inner panel which allows for routing cables down the legs. All cables must be disconnected before moving equipment, or unit could become unstable and either tip or collapse.
- It is recommended to have assistance when assembly steps require flipping unit over, stacking second (2nd) tier, or units require moving into place.
- Excercise caution if you see this (symbol) 🛕 in the instruction guide.
- · Wipe clean with a cloth dampened in a mild cleaner, then wipe dry with a clean cloth.























































## HINGES

SOFT-CLOSE HINGE MAY NEED ADJUSTMENT SCREWS TURNED IN ORDER TO PROPERLY ALIGN TOP

